

Einbauanleitung



ZRV M , ZRE M

EN Installation manual

FR Instructions de montage

NL Montagehandleiding

IT Guida per il montaggio

ES Instrucciones de montaje

PT Instruções de instalação

PL Instrukcja montażu

CZ Montážní návod

SK Návod na montáž

SI Navodila za vgradnjo

RU Руководство по монтажу

GR Οδηγίες τοποθέτησης

EE Paigaldusjuhend

LV Uzstādīšanas instrukcija

LT Montavimo instrukcija

RO Manual de montare

HU Beépítési útmutató


HR Upute za ugradnju

BG Монтажна инструкция

Roto Rx



Roto Q.4





Roto Rx4

WDF, WDT, WDA, WRA, WDC, WSA



Roto Q.416


Q, QT




.....30



Roto Rx








1






Roto Rx

2




3






Roto Rx

4











Roto Rx

6



7





PZ 1






Roto Rx

8




9





Roto Rx

10




11







Roto Q.4







1






Roto Q.4

2




3







Roto Q.4





5






Roto Q.4


6



7





PZ 1








Roto Q.4

8




9





Roto Q.4

10





11








Roto Rx / Roto Q.4





1**2****3**

3





The roof window.



www.roto-contacts.com



www.roto-extra.com

Roto Frank DST Vertriebs-GmbH
Wilhelm-Frank-Straße 38-40
97980 Bad Mergentheim
Deutschland

