

Special Features:

- Length: 270, 300, 350, 400, 450, 500, 550mm.
- The drawer side-board is 88mm high.
- Drawer width can be designed freely with automatic error adjustment.
- Hidden full pulout silencing sliding slide can bear 40kg and enjoys excellent stability and quiet and smooth sliding performance.
- Quick installation and dismantle.
- Newly-designed built-in damper is free from reinstallation and ensures soft and smooth drawer movements.


Basic length	Internally usable drawer depth	Minimum installation depth of drawer	Minimum installation height
300mm	274mm	300mm	110mm
350mm	324mm	350mm	110mm
400mm	374mm	400mm	110mm
450mm	424mm	450mm	110mm
500mm	474mm	500mm	110mm
550mm	524mm	550mm	110mm

1. Guide Left/Right Length:



300mm
350mm
400mm
450mm
500mm
550mm

2. Drawer Side & Decorative Cap Left/Right Length:



300mm
350mm
400mm
450mm
500mm
550mm


3. Back connector Left/Right



4. Front connector Left/Right




Runner Installation(mm)




Basic length: 300/350/400/450/500/550

Technology pivot:
Bottom and Back Panel Measurement
16MM Density Panel




- 1 Bottom panel width=Inside Cabinet Width-75±0.5
 - 2 Back panel height= 68MM
- Back panel width=Inside Cabinet Width-87±0.5


Inside Cabinet Dimension




Front Panel Mounting Positions




Front Fixing Brackets Positions



Back Panel Mounting Positions




Front fixing brackets mounting



Front panel height adjustment : ±2mm

B Side overlay(user-defined)


- 1 Installed panel
- Remember that tighten the fixing screw



Front panel side adjustment : right/mm

A B Side overlay(user-defined)


- 1 Take out the plastic cover




Front panel side adjustment : left/mm

Back Panel Mounting Positions


- 1 Loosen the fastening screws
- 2 Rotation to dismantle the panel







Mounting the drawer











Installing the drawer






Function of the damper



Removing the drawer



Function of the damper



Push the metal spring part from the panel & pull out